

MOCREO SW3

Water Leak Sensor

USER MANUAL

V1.0

Introduction

- SW3 Water Leak Sensor has detection contacts on the top, the side and the bottom of the housing, so water is detected wherever it reaches the unit first.
- The sensor sends leak data to the Hub over Bluetooth LE, up to 131 ft under ideal conditions.
- The Hub uploads the data to the cloud over Wi-Fi (2.4 GHz), so you can check the status and receive alerts in the App from anywhere.
- IP67 rated housing, powered by two AAA batteries.

Hub Compatibility

SW3 works with the **H6Lite Hub only**. It is not supported by other Hub models. The Hub is sold separately.

Water Leak Detection Contacts

- **Top contacts** — detect water dripping onto the sensor from above.
- **Side contacts** — detect rising water at the side of the housing.
- **Bottom contacts** — detect water on the surface the sensor stands on.

Specifications

Item	Description
Model	SW3
Wireless Protocol	Bluetooth LE
Communication Range	131 ft (under ideal conditions)
Dimensions (H×W×D)	74 mm × 60 mm × 26 mm
Weight	83 g (2.93 oz)
Power Supply	2 × AAA Batteries
Operating Temperature	32°F to 122°F (0°C to 50°C)
Waterproof & Dustproof Rating	IP67

Indicator & Button Behavior

Function	Indicator Response
Power On / Restart	Red light flashes once.
Water Detected	Red light flashes slowly and continuously.
Water Cleared	Light off.
Setup Button — Single Press (Send Data)	Red light flashes once.

Setup

Add the H6Lite Hub in the App first, then add the SW3 Sensor. Follow the on-screen instructions in the App to complete the setup.

Keep the Bluetooth of your mobile device enabled during the whole setup process.

Battery Replacement

Use a screwdriver to remove the four screws on the bottom cover of the sensor, then replace the two AAA batteries. Make sure the waterproof seal and the cover are seated correctly before tightening the screws.

Precautions for Use

- Do not expose the device to high temperatures, humidity, or dusty environments.
- Do not place the device near flammable materials.
- Do not put heavy objects on the device or use it as a support.
- Children should not use the device without adult supervision.

Disclaimer

The contents about how to use the product and the App guidance are only for reference; please refer to the actual situation for specific applications. If there is something different from the instructions during using the product, please contact MOCREO Support for updates. This product is for detecting and monitoring only. MOCREO is not responsible for any property damage or other consequences of the use of this product.

Warranty

MOCREO products enjoy a 12-month limited warranty (starting from the date when the customer receives the product), which applies only to hardware components of the device that are not subject to accident, misuse, neglect, fire, or other external causes, alterations, or repair.

Customer Service

help@mocreo.com